



Nexus S Rear Inner Frame Replacement

Replace the rear inner frame in your Nexus S.

Written By: Walter Galan



INTRODUCTION

This guide will help you replace the rear inner framework.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Rear Panel



- Gently insert a plastic opening tool between the rear panel and the inner rear frame near the rear-facing camera.
- Use your plastic opening tool to pry up the rear case around the perimeter of the Nexus S.

Step 2



- Remove the rear panel from the Nexus S.

Step 3 — Battery



- Using the edge of a plastic opening tool, lift the battery from the end closest to the headphone jack.
- Remove the battery from the Nexus S.

Step 4 — SIM Card



- Use your thumb to slide the SIM card downwards from the SIM card slot.
- Remove the SIM card.

Step 5 — Rear Inner Frame



- Remove the six Phillips screws securing the rear inner frame to the inner case.

Step 6



- Insert the flat edge of a plastic opening tool in between the rear inner frame and the top left corner of the Nexus S.
- Pry the opening tool upwards to pop the top right corner from the clips securing it to the inner assembly.

Step 7




- Insert the plastic opening tool to the right of the power button.
- Slide the plastic opening tool downwards along the perimeter of the Nexus S to release the clips on the right side.

Step 8




- In the same manner as previously described, release the bottom clips located near the bottom of the Nexus S.

Step 9



- Insert and pry the plastic opening tool to release the final clip securing the rear inner frame to the inner assembly.

Step 10



- Lift and remove the rear inner frame from the Nexus S.

Step 11 — Rear Inner Frame



- Rear inner frame remains.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 05:09:37 PM.